ICOM INSTRUCTIONS

DESKTOP MICROPHONE

this product. carefully and completely before using product. READ ALL INSTRUCTIONS Thank you for choosing this Icom

with an Icom transceiver The SM-50 is an unidirectional, dynamic microphone designed for base station operation

PRECAUTIONS

be damaged. rain, snow or any liquids. The microphone may CAUTION: NEVER expose the microphone to

CAUTION: NEVER touch or operate the CAUTION: NEVER let metal, wire or other connector objects protrude into the microphone or into

CAUTION: NEVER use harsh solvents such as desktop microphone with wet hands

will damage the microphone's surfaces benzine or alcohol when cleaning, because they

transceivers have different pin assignments and transceivers only. Other manufacturer's may damage the transceiver or microphone if CAUTION: USE with specified Icom

DO NOT place the microphone in excessively direct sunlight or in areas with temperatures below -10°C (+14°F) or above +60°C (+140°F). DO NOT operate or place the microphone in

to avoid inadvertent use by unauthorized persor Always place the microphone in a secure place

About CE

The SM-50 complies with the 2014/30/EU directive for essential requirements of the

the 2001/95/EC directive for General Product Electromagnetic Compatibility and

DISPOSAL



or packaging reminds you that in symbol on your product, literature and accumulators (rechargeable and electronic products, batteries the European Union, all electrical The crossed-out wheeled-bin

according to the laws in your area unsorted municipal waste. Dispose of them collection locations at the end of their working life. Do not dispose of these products as batteries) must be taken to designated

SPECIFICATIONS

Microphone type:

55 Ω ±30% (at 1 kHz Unidirectional dynamic microphone (preamp built-in)

 Sensitivity: Output impedance:

-30 dB ±4 dB (at 1 kHz, 0 dB=1 V/Pa)

· Cable length (approximate): 1 m, 3 ft 3% in 5-10 V DC (supplied from the transceiver


Power requirements:

 Weight (approximate): 730 g, 26 oz

All stated specifications are subject to change without notice or obligation.

PART NAMES AND FUNCTIONS

♦ FRONT VIEW



• FREQUENCY UP/DOWN SWITCHES [UP]/[DOWN] Push to change the frequency.

Hold down to change the frequency continuously.

LOW CUT SWITCH [LOW CUT]

input voice signals. Push to cut out the low frequency components of

3 PTT SWITCH [PTT]

Push to transmit, then release to receive

PTT LOCK SWITCH [LOCK]

continues until pushing this switch again Push to transmit continuously. The transmission

OBOTTOM VIEW



MIC GAIN VOLUME [MIC GAIN:


Rotate to adjust the microphone output level

 Use this control as an adjunct to the microphone gain setting of the connected transceiver.

may result in over-modulation and transmit signal NOTE: Rotating the control too far clockwise distortion.

♦ PLUG PIN ASSIGNMENTS

The pins are described from the direction of the arrow in the illustration



① Microphone output No connection ③ GND (Microphone ground)

GND (PTT ground)

4 No connection ⊕ P∏

equipment, if the malfunction is because of: lcom is not responsible for the destruction, damage to, or performance of any Icom or non-Icom

- Force majeure, including, but not limited to, fires, earthquakes, storms, floods, lightning, other natural disasters, disturbances, riots, war, or radioactive contamination
- The use of Icom transceivers with any equipment that is not manufactured or approved by Icom.

United Kingdom, Germany, France, Spain, Russia, Australia, New Zealand, and/or other countries. and/or other lcom, Icom Inc. and the Icom logo are registered trademarks of Icom Incorporated (Japan) in the United States, the

com Inc.

1-1-32 Kamiminami, Hirano-ku, Osaka 547-0003, Japan

Count on us!

A-6706X-1G-2 Printed in Japan © 2008-2016 Icom Inc